



## Homemade Microwave Popcorn



$\frac{1}{4}$  c popcorn kernels

1 small brown paper bag

1 T butter, melted

$\frac{1}{4}$  t salt

Place kernels in bag. Make a 1-inch fold at top of bag; fold again. Lay bag folded side down in microwave and heat for 2 minutes or until popping slows to one per second. Empty popcorn into bowl. Pour butter over popcorn and sprinkle with salt. Stir and serve.